

Basket Strainer Parts



Basket



SS-308 Basket



Grid



Brass Tail nut



Zinc Lock Nut

Basket Parts

Part No.	Model	Piece
301-001	SS 304	Basket
301-021	SS 305	Basket
301-002	SS 306	Basket
301-003	SS 410	Basket
301-004	SS 420	Basket
301-005	SS 430	Basket
301-006	SS 440	Basket
301-010	SS 308	Basket
301-011	SS 310	Grid
302-101	-	Rubber Gasket
302-102	-	Paper Follower

Brushed Stainless Basket Strainer/Disposer Parts

Part No.	Model	Piece
301-017	BS 313B	Basket
301-018	BS 314-DFC	Cover (with rubber seal)
301-019	BS 315	Basket
301-020	BS 315 & BS 316	Grid

Locknuts and Tail nuts for Models SS-304, SS-410, SS-430

Part No.	Piece
302-103	Zinc Lock Nut
302-104	Brass Lock Nut
302-105	Zinc Tail Nut
302-106	Brass Tail Nut

Cut Type Locknut for Models SS-306, SS-420, SS-440, SN-307B

Part No.	Piece
302-105	Zinc Tail Nut
302-106	Brass Tail Nut
302-107	Zinc Lock Nut for Cup Type
302-108	Brass Lock Nut for Cup Type
302-109	Plastic Tail nut Washer
302-199	1-1/2" x 4" Chrome Tailpiece